1 Date

2 Teams 19 & 20: Communications Protocol

Specification Document

4 Laboratory #2: Requirements and Specification

Morgan, Laura
 Miaw, Jireh
 Hauser, Steven
 Dworak, Catherine

Lenig, Tyler
Tang, Raymond
Rupakhetee, Archit
McMillion, Andrew

9 Bertoglio, David

10 11

3

12 Work Product

13 This document describes the communication protocol implemented by Teams 19 and

20 for communication between the base station control system, and the robot. This

document describes the creation, and decoding process for messages.

16

14

17 Document Revision Information

- 18 **2/15/2013** created
- 19 2/17/2013 designed base station to robot messages
- 20 **2/22/2013** continued design
- 21 2/24/2013 designed robot to base station messages

Approval Sheet All group members whose names are listed below approve of the document and contributed fairly. **Member Names Group 19 representative Dworak, Catherine Group 20 representative** Lenig, Tyler Pledge On my honor, as a student, I have neither given nor received unauthorized aid on this assignment. Names Group 19 Morgan, Laura Miaw, Jireh Hauser, Steven **Dworak, Catherine** Bertoglio, David Group 20 Lenig, Tyler Tang, Raymond Rupakhetee, Archit McMillion, Andrew

Table of Contents

67	Introduction	4
68	About	4
69	Protocol Description	4
70	Base Station to Robot Messages	5
71	Command Structure	
72	No-On	5
73	Move Straight	5
74	Move Arc	5
75	Turn	6
76	Stop	6
77	Read Sensor	6
78	Set Speed	6
79	Read All Sensors	6
80	Robot to Base Station Messages	7
81	Acknowledgment	
82	Error Messages	
83	Sensor Error Messages	7
84	Motor Error Messages	
85	Sensor Data Messages	
86		

Introduction 88 89 **About** 90 This document describes the protocol used to communicate between robot and base 91 station system. This protocol allows the base station to control the robot, and allows 92 the robot to send messages including errors to the base station. 93 94 **Protocol Description** 95 This protocol uses 10-character messages to communicate between the robot and 96 the base station. These 10-character messages encode both commands from the 97 base station to the robot and messages from the robot to the base station. The 98 messages are structured such that the first two characters determine the type of 99 command or message. The remaining characters are used for various parameters that are documented below. 100

102	Base Station to Robot Messages			
103 104 105 106	Command Structure Commands are 10-character messages, where the first two characters are the command type. The remaining characters represent parameters to the command, used by the robot to determine how to execute the command.			
107	No-Op			
108	Message: 0000000000			
109 110	Description: This command is the no operation command can be used to test if messages are being sent. This message is a "null" message.			
111	Move Straight			
112	Command Type: MS			
113	Parameters: Forward/Backwards, and distance.			
114	Byte 2 is forward or backwards (F/B)			
115	Bytes 3-9 is distance (#), can be null (0s)			
116	Description: This command moves the robot in a straight line. The			
117	forward/backward parameter control the direction the robot will move in. The			
118	distance allows for the robot to move a specified distance, this parameter can be			
119	null. If distance is null, the robot will continually move			
120	Example Commands:			
121 122	MSF000000 will move the robot forward continuously. MSB0001000 will move the robot backwards 1000 units.			
123	Move Arc			
124	Command Type: MA			
125	Parameters: Forward/Backwards, left/right, radius, distance			
126	Byte 2 is forward or backwards (F/B)			
127	Byte 3 is left or right (L/R)			
128	Byte 4-6 is radius (# degrees)			
129	Byte 7-9 is distance (#), can be null (0s)			
130	Description: This command moves the robot in an arc. The forward/backward			
131	parameter control the direction the robot will move along the arc. Left/Right will			
132	control the direction the robot arcs to. Radius is the absolute value of the number of			
133	1			
134	parameter can be null. If distance is null, the robot will continually move until			
135	stopped.			
136	Example Commands:			
137	MAFL090000 will move the robot forward to the left along a 90 degree curve			
138	continuously			
139	MABR030100 will move the robot backwards along a 30 degree curve for			
140	100 units.			
141				

142	Turn
143	Command Type: TN
144	Parameters: Left/Right, and radius
145	Byte 2 is left or right (L/R)
146	Byte 3-9 is radius (# degrees), can be null (0s)
147	Description: This command turns the robot when stationary. The Left/Right
148	parameter determines the direction the robot turns. The Radius parameter is an
149	absolute value that determines how far the robot turns. If the radius is null, the
150	robot continually turns until stopped.
151	Example Commands:
152	TNR0000090 will turn the robot right 90 degrees
153	TNL0000000 will turn the robot left continuously
154	Stop
155	Message: ST00000000
156	Description: This command stops any actions that the robot is currently doing. This
157	will end any movement actions.
158	Read Sensor
159	Command Type: RS
160	Parameters: Sensor Port
161	Byte 2 is sensor type (U for Ultrasonic, T for touch, M for sound, L for light)
162	Bytes 3-9 are 0
163	Description: This command will read a specified sensor. The Sensor Port parameter
164	will determine which sensor to read the value of.
165	Example Commands:
166	RSU0000000 will cause the robot to read the value of the sensor, and send
167	the data to the base station.
168	Set Speed
169	Command Type: SS
170	Parameters: Motor/Motor Combination, and new speed.
171	Byte 2 is Motor/Motor combination (A for Motor A, B for Motor B, C for
172	Motor C, D for Drive Motors)
173	Bytes 3-9 is the new speed
174	Description: This command will change the speed of the motors. The combination
175	will determine which motors or combinations of motors to change the speed for.
176 177	Example Commands:
178	Read All Sensors
179	Command Message: RA00000000
180	Description: This command tells the robot to read all sensors and send the data.
181	Each sensor's data will be sent to the base station in a separate message.

182 Robot to Base Station Messages

183 Acknowledgment

184 **Description:** This message is sent to the base station as acknowledgment of

185 receiving a command.186 **Message: AK00000000**

187 Error Messages

188 Sensor Error Messages189 Message Type: ERS

190 **Parameters:** Message number191 Bytes 3-9 message number

Description: This message will tell the base station that an error with a sensor has occurred. The message number maps to a more specific description, that the base station will have stored locally for reference. Available messages can be seen in a

table below, which will have additions added as required.

195 196

192

193

194

Message Number	Description
0000001	Error with sensor in port 1
0000002	Error with sensor in port 2
0000003	Error with sensor in port 3
0000004	Error with sensor in port 4

197

201

202

203

204

198 Motor Error Messages

199 Message Type: ERM200 Parameters: Messag

Parameters: Message Number Bytes 3-9 message number

Description: These messages will tell the base station that an error with a motor has occurred. The message number correlates to a specific description, which the base station has stored locally. Available messages can be seen in a table below,

which will have additions added as required.

205206

Message Number	Description
0000001	Error with motor in port A
0000002	Error with motor in port B
0000003	Error with motor in port C

207

208

211

Sensor Data Messages

209 **Message Type:** SD

210 **Parameters:** Sensor Type, and Data

Byte 2 sensor type (U for Ultrasonic, T for Touch, M for Sound, or L for Light)

212 Bytes 3-9 sensor data

Description: These messages allow for the robot to send data to the base station

based on the values of the sensor.